

ASSEMBLY INSTRUCTIONS:

1. MEASURE THE BOTTOM PLATE TO YOUR INJECTION FOR HOLE PLACEMENT.
2. CUT HOLES TO LINE UP WITH YOUR INJECTION.
3. USE RUBBER SEAL AS TEMPLATE TO LOCATE RIVET HOLES.
4. DRILL OUT RIVET HOLES.
5. APPLY A BEAD OF SILICONE ON THE UNDERSIDE OF THE RUBBER SEAL.
6. PLACE RUBBER SEAL ON BASE PLATE THROUGH HOLES YOU CUT.
7. USE RIVETS TO FASTEN BASE PLATE TO RUBBER SEAL.

